

# Mounting instructions

## 01 Key Holder

weld & co

### PLEASE NOTE:

The key holder are intended for mounting on masonry walls using wall anchors and screws which are included in the delivery. When hanging the picture ledge on walls made of lightweight materials (drywall or similar), anchors which are suitable for the wall material must be used - these are NOT included. Some types of wallboard do not require the use of wall anchors.

### MOUNTING:

1. Using a spirit level and a pencil, draw an approx. 25 cm line on the wall where you plan to hang the key holder.
2. For masonry walls: Using a 6-mm bit, drill two approx. 4-cm-deep holes into the wall, spaced 20 cm.
3. For masonry walls: Insert wall anchors into the holes and carefully tap them into place using a hammer.
4. Place a screw into each anchor and tighten it with a screwdriver until about 1 cm is still visible.
5. Using the holes in the key holder, hang it onto the screws. If the wall is uneven, you may have to tighten or loosen the screws until the key holder fits snugly against the the wall on both sides.

### TECHNICAL SUPPORT:

post@weldco.de

### YOU'LL NEED:

Spirit level  
Pencil  
Drill  
6-mm drill bit  
(please select an appropriate drill bit for your wall material)  
Hammer  
Phillips screwdriver

