

Mounting instructions

01 Wall Mirror

weld & co

PLEASE NOTE:

The mirror and its wood shelf are intended for mounting on masonry walls using wall anchors and screws which are included in the delivery. When hanging the shelf on walls made of lightweight materials (drywall or similar), anchors which are suitable for the wall material must be used - these are NOT included. Some types of wallboard do not require the use of wall anchors.

MOUNTING:

1. Using a spirit level and a pencil, draw an approx. 80 cm line on the wall where you plan to hang the wall mirror.
2. For masonry walls: Using a 6-mm bit, drill two approx. 4-cm-deep holes into the wall, spaced 70 cm apart.
For drywall, etc.: If necessary, screw in two wall anchors spaced 70 cm apart.
3. For masonry walls: Insert wall anchors into the holes and carefully tap them into place using a hammer.
4. Place a screw into each anchor and tighten it with a screwdriver until about 1 cm is still visible.
5. Using the holes in the wood shelf, hang it onto the screws. If the wall is uneven, you may have to tighten or loosen the screws until the ledge fits snugly against the wall on both sides.
6. Insert the mirror in the slot provided for it.

OUR TIP:

Get a second person to help you hang the picture ledge.

PLEASE NOTE:

The full load-bearing capacity of the wall mirror can only be met if it is securely and correctly attached to the wall.

TECHNICAL SUPPORT:

post@weldco.de

YOU'LL NEED:

Spirit level
Pencil
Drill
6-mm drill bit
(please select an appropriate drill bit for your wall material)
Hammer
Phillips screwdriver

